Custom
Decorative Hardware
Installation Instructions

Threading a Traverse Track | Cord Draw - Center Draw

Knot Cord End B   Knot Cord End A

This cord passes under the
opposing master carrier cord block.

Place the cord under the hook after
threading through the track and the cord
tension device is complete and the master
carriers come together.

Cord Threading Diagram
(shown from the back side)

Cord Tension Device

Sample Images
(shown from the back side)

1