

Square Grommet Panels

Grommets are an easy way to add interest and movement to a drapery panel.

Materials & Supplies

Rowley Products

Straight Edge Ruler - 72" Long Scissors

Whyte & Ivory, Cambridge Napped Sateen Lining

John James Hand Sewing Needles

Lead-Free Drapery Weights R-TEX Pressure-Sensitive Adhesive

Buckram - 3/8" Wide

Fabric Stapler

Fabric Stapler Staples

Magnetic Staple Remover

Grommet Spacing Template

Pen Style Chalk Markers

Brass Square Grommets - #12

Grommet / Button Press

Grommet Cutter - #12

Grommet Setter - #12

SKU

MR26

CU22

LNW48/

TP118

SW37

BNP34/T

WW70

WW71

WW72

DYC90

WW13/

GQ12/

GL

GL12/C

GL12/SQ



Square Grommet Panels: Step-By-Step Instructions

Explore how to create these grommet panels with square grommets to coordinate with the geometric pattern of the fabric, plus step-by-step instructions and tips for setting grommets.



Preparing the Pieces:



Cut face fabric widths as needed and join, making a perfect pattern match at the join seam. Sew join seam.











- Fold in a double 4" bottom hem. Press.
- Add drapery weights at the join seams.
- Close hem using your preferred method.
- Cut and join lining widths as needed. Fold in a double 3° bottom hem. Iron and hem.











Laying out the Panel:







- Fold in double 1 $\frac{1}{2}$ " side hem on both sides. Press.
- Add a drapery weight at the bottom corners and close using your preferred method.





- Measure for finished length.
- Trim and turn under a double 4" header, adding a row of buckram.

Finishing the Panel:

Lay panel on table so face is up with the top header facing you along one long side of the table.

Follow the directions on the grommet template to set placement of grommets.











Once one panel is marked, move the other panel to the table, with wrong sides together mark the second panel.



At the grommet machine, cut each grommet circle, cutting through all layers.







Set all grommets on square.

To keep grommets from shifting while setting, place small pieces of tape on the corners of the front and back grommet pieces before setting. This will help the grommets stick to the fabric and not shift.





Hand close the sides of the header.



