


Sure-Shade™ Universal Drive Tension Device Installation Instructions

Please read all instructions before installing

WARNING: It is imperative that the drive tension device for bead chain loop be properly secured to the wall or window frame to reduce a child's access to the bead chain loop. Young children can wrap bead chain loop around their necks and strangle. Always keep bead chain loop secured and out of reach of children.

NOTE TO MANUFACTURER OR FABRICATOR: The shade will not operate properly unless the drive tension device is secured to comply with ANSI/WCMA standard section 6.5.2.

PARTS LIST (see Figure 1):

1. One Assembled Device
2. One Slider
3. Slider Lock
3. Two Brackets: one for inside mount and one for outside mount
4. One 1 ½" long #4 wood screw and two 1 ½" long #6 wood screws
5. One Cable Tie (not shown)
6. Instructions  Slider Lock




Figure 1

ATTACH DEVICE TO BEAD CHAIN LOOP

(see Figure 2): Drop the bead chain in the device. While pulling the screw hole part down, insert the slider from the side into the center of the device and push up, into place. Now the device is attached to the loop. The device can easily move along the loop by pulling down the screw hole.




Figure 2

INSTALL THE SLIDER LOCK:

Install Slider Lock by hand into the Slider (Figure 3A).




Figure 3A

Use Needle Nose Pliers to push the Slider Lock into the Slider (Figure 3B).




Figure 3B

Press on the right side of the Slider Lock until a click is heard (Figure 3C).




Figure 3C

Press on the left side of the Slider Lock until a click is heard (Figure 3D).




Figure 3D


To verify installation, ensure the Slider Lock is flush to or below the surface of the Slider (Figure 3E).



Figure 3E


NOTE TO SHADE FABRICATORS TO COMPLY WITH ANSI/WCMA STANDARD, SECTION 6.5.1:

Pull either side of the drive loop as shown in Figure 4 until the shade is lifted completely up to the headrail. Using the specific side of the drive loop that was pulled to raise the shade, attach the device as described above.



Pull either side of drive loop
Figure 4

While pulling down on the screw hole of the device, slide the device up as close as possible to the headrail as shown in Figure 5.



Drive Tension Device
Figure 5

Route a cable tie through the oval shaped hole on the device and completely around the bundled up drive chain loop, and tighten the cable tie securely as shown in Figure 6.




Figure 6

INSTALL DEVICE:

You can install the device inside or outside the window casing using the correct bracket. Make sure the device is not placed in the path of the bottom rail of fabric. At the job site, use cutting pliers to carefully snip and remove the cable tie from the device. Slide the device to the bottom of the tool while pulling the screw hole in the device as shown in **Figure 7**. The device must be properly and securely mounted with tension on the drive loop for the shade to be fully operatable.





Figure 7

INSIDE MOUNT (See Figure 8):


1. Attach the device to the inside mount bracket with the short screw as shown in **Figure 8A**. The nub on the bracket fits into the back of the screw hole on the device.
2. Pull down on the bracket, align the center of the screw hole part with the indicator line on the device as shown in **Figure 8B**.



3. While holding the device firmly in place, check if the loop can move freely through it.
 - a. If the device locks onto the loop, it is too loose and the bracket and device should be moved down.
 - b. If the loop does not run freely through the device, it is too tight and the bracket and device should be moved up.
4. Mark and pre-drill the screw holes.
5. Pull down on the bracket and device, align it with the drilled holes, and mount the bracket to the inside window casing with two long screws.
6. Check to ensure the loop can move freely through the device without engaging the lock.

OUTSIDE MOUNT (See Figure 9):

1. Attach the device to the outside mount bracket with the short screw as shown in **Figure 9A**. The nub on the bracket fits into the back of the screw hole on the device.
2. Pull down on the bracket, align the center of the screw hole part with the indicator line on the device as shown in **Figure 9B**.



3. While holding the device firmly in place, check if the loop can move freely through it.
 - a. If the device locks onto the loop, it is too loose and the bracket and device should be moved down.
 - b. If the loop does not run freely through the device, it is too tight and the bracket and device should be moved up.
4. Mark and pre-drill the screw holes.
5. Detach the device from the bracket by removing the short screw. Align the bracket screw holes with the drilled holes and mount the brackets to the wall with two long screws.
6. Reattach the device to the bracket with the short screw.
7. Check to ensure the loop can move freely through the device without engaging the lock.

NOTE: Bead chain connectors or stops will cause a slight jump when going through the device. Certain brands of bead chain connectors may not work with the device.