

# Cornice Board Padding

**2 Widths: 18" & 36"**

<u>STOCK#</u>	<u>Width</u>	<u>Length</u>
<b>PA27/18</b>	<b>18"</b>	<b>90 ft.</b>
<b>PA27/36</b>	<b>36"</b>	<b>90 ft.</b>



- High density, approximately  $\frac{3}{8}$ " thick, polyester fiber.
- Fire Retardant.
- Ideal for upholstered cornice boards as well as soft cornices.
- Can be butted, retains its shape and can be wrapped around corners.
- Can also be used for place mats, upholstery, etc.
- Can use our spray adhesive (AS30) to adhere to board.
- White color.

*For more finished looking cornice edges, we recommend using our Tack Strip.  
 Stock# **CS50** or Stock# **CS38***

## ***4 Simple Steps***

- 1-*** Lay board down on padding.
- 2-*** Trace outline with a marker.
- 3-*** Remove board and cut out design.
- 4-*** Adhere to board.