

Custom Banded & Button-Detail Duvet Cover

Duvets are both functional and fashionable, providing flexibility in weight and style. Combined with stylish covers, duvets can create the perfect solution for your customers. Follow along and learn how to create custom duvet covers to fit any bedding project.



Materials & Supplies

Rowley Products Item # R-TEX Polyester Duvet Insert DU Straight Edge Ruler **MR26** Glass Head Straight Pins **TP49 Invisible Zippers EVP, EVR** Crimp Button Forms, #36 FCA36 Grommet / Button Press GL Cutting & Setting Die Sets for Crimp Button Form **GLA36, GLH36**

Custom Banded & Button-Detail Duvet Cover: Step-By-Step Instructions

Duvet Cover:



For a 96" x 96" Finished Length (FL) size, cut face fabric 98" (solid color fabric) and fabric for the back of the cover 98". Cut enough widths to allow for the center panel of the duvet cover to be cut down to 41". If the fabric width is 54", it may be necessary for to have three widths of fabric.



Cut, pin, and seam face fabric and lining. Surge for a clean finish inside the duvet cover.



- Press seams.
- Add flat braid trim to duvet cover at seams. Use iron on bonding tape or glue baste to attach before top stitching.



A. Use a long ruler as a guide to help in placing the trim to the duvet cover. If using iron on bonding tape, remove protective paper from tape.



- Cut strips and make enough welt cord to go around all four sides of the duvet cover.
- Pin the snaps to the wrong side and stitch the snaps to the duvet cover as you are sewing the welt to the duvet cover.







Insert an invisible zipper at the foot of the duvet cover centering this between the flat braid trim.



Pin the remaining three sides of the duvet cover together and stitch.



Serge around the edges of the duvet cover for a clean finish.



Snap the duvet insert to the duvet cover and turn right sides out.









