


Wood Hardware Display Board

Thank you for purchasing your new display board. With proper installation and care, it will provide you or your customer with years of beauty and trouble-free functionality. Clean with a soft cloth. Do not use harsh or abrasive cleaning supplies or polishes, which may damage the finishes.

Tools Needed for Installation (not included):

- Tape measure and pencil
- Level
- Power drill with 1/8" drill bit for screws and / or 3/16" drill bit for plastic plug
- . #2 Phillips bit or screw driver



Wood Hardware Wall Display Installation

- 1. Determine the height of the top of the display board.
- Measure down from that height 14 ¾ " and mark. This will be the level of the bottom edge of the upper cleat.
- 3. Measure down an additional 42" from that mark (56 ¾" from the top of the display) and mark. This will be the placement of the bottom edge of the lower cleat.
- 4. Hold the cleats in place on their marks, making sure they are level and square. Mark the location of the holes.
- Install the anchors in the wall at the marked hole location then screw the cleats to the wall using the supplied screws.
- Install standoffs in the outer holes on the top of the display board using the supplied ¼" x 1" long screws.
- Install sign by removing caps from standoffs, slide the screw through the holes in the sign and re-assemble the stand-off.
- 8. Hang the display.
- Install bracket plates using the top hole of the plate and the top hole that is pre-drilled on the display board.
- 10. Place finials on the poles in the order to the right.
- 11. Place poles in the appropriate brackets.

Wood Hardware Traverse Track Installation

- 1. Install finial clips at each end of the pole.
- Install fascia clips to the route so the lip sits on the bottom of the route. Clips must not align with the wall bracket.
- 3. Install wall brackets to display board.
- 4. Lock track into brackets.
- 5. Snap on fascia.
- 6. Install finials.



FSW3000/W